



Cisco BroadWorks 功能同步配置手册





一,	前言	
	1. 功能介绍	2
	2. 注意事项	
_,	配置流程	2
三、	配置操作	
	1、配置 Cisco BroadWorks	٥
	①登录 Cisco BroadWorks	S
	②分配需要同步的功能	4
	③开启功能同步	5
	2、 配置 IP 话机	6
	①开启功能同步	6
四、	检验结果	8
	1. 在 Cisco BroadWorks 上开启免打扰功能	8
	2. 在话机上关闭免打扰功能	Ć



一、前言

1. 功能介绍

功能同步是 Cisco Broadworks 的特色功能之一,它可以使话机上的某些功能更改状态时将状态同步到服务器,避免了由于两者不同步带来的错误,如通话中断。举个例子,当用户在话机上将免打扰打开时,服务器上分配给该话机的线路同样显示免打扰已打开。反之,用户在服务器上将该线路的免打扰打开,话机也将显示免打扰已打开。

2. 注意事项

1. 功能同步支持同步状态的常用功能有:

免打扰 (DND)

无条件呼叫转移(CFA)

遇忙转移(CFB)

无应答转移(CFNA)


呼叫中心签入/签出

行政助理 (Executive)

通话记录

2. 本文旨在为使用 Cisco Broadworks 作为 SIP 服务器,使用飞音 IP 话机作为终端的用户提供功能同步的操作引导。

二、配置流程





三、配置操作

1、配置 Cisco BroadWorks

①登录 Cisco BroadWorks

操作步骤:浏览器输入 Cisco BroadWorks 地址--》输入 User ID(用户名)及 Password(密码)--》 点击 Login(登录)--》登陆成功--》进入需要使用的线路对应用户界面。

ախախ CISCO



Copyright © 2020 Cisco and/or its affiliates. PROPRIETARY AND CONFIDENTIAL - ALL USE MUST BE LICENSED

All use of the material herein must be in strict accordance with the terms of the license you have entered into with Cisco. All rights not expressly licensed are reserved

图 1 登录进入 Cisco BroadWroks




图 2 登录成功

3

sales1@flyingvoice.com




图 3 进入用户界面

②分配需要同步的功能

操作步骤: Assign Service--》选择所需功能(此处以 DND 为例)--》Add--》所需功能出现在 右侧方框--》Apply。




图 4 分配服务(一)





Assign Services

Assign Services allows you to assign or unassign services and service packs for a user. If a service or service pack is unassigned the service data that has been fill



图 5 分配服务(二)


③开启功能同步

操作步骤:

Profile--》Device Policies--》勾选 Single User Private and Shared Lines--》勾选 Enable Device Feature Synchronization--> Apply.



图 6 开启功能同步(一)








图 7 开启功能同步(二)

2、配置 IP 话机

确保 IP 话机已经注册以上配置的线路。该步骤在飞音话机 Web 界面上操作。

①开启功能同步

FLYÍNGVOICE

操作步骤: VoIP--》账号 x--》功能同步选择开启--》保存并应用。



图 8 开启功能同步(一)





图 9 开启功能同步(二)



图 10 开启功能同步(三)



四、检验结果

1. 在 Cisco BroadWorks 上开启免打扰功能

操作步骤:

Incoming Calls--》Do Not Disturb--》勾选 On--》Apply--》话机状态随之自动改变。




图 11 Cisco BroadWorks 开启免打扰(一)




图 11 Cisco BroadWorks 开启免打扰(二)



图 12 测试成功, 话机状态随之改变



2. 在话机上关闭免打扰功能

操作步骤:

按下话机上对应按键关闭免打扰--》服务器上状态随之变成 Off(关闭)。

Incoming Calls Advanced Call Forwarding Always - Off Priority Alert - On Ring your phone with a distinctive ring when pre-defined criteria, such as phone number, time of day or day of week, are met. Automatically forward all your incoming calls to a different phone number. Call Forwarding Busy - Off Automatically forward your calls to a different phone number when your phone is busy. Call Forwarding No Answer - Off Automatically forward your calls to a different phone number when you do not answer your phone after a certain number of rings. Do Not Disturb - Off Automatically forward your calls to your voice messaging service, if configured otherwise the caller hears a busy tone. External Calling Line ID Delivery - On Provides Calling Line ID information of an external caller. Internal Calling Line ID Delivery - On Provide Calling Line ID information of group or enterprise member when called.

图 13 测试成功,服务器状态随之改变

9